

# Linear®



## TE Front Panel Guide and Configuration Manual



### 1. Navigation

The **HOME** button will take you "back" to a previous screen.

Pressing HOME repeatedly will eventually return you to the WELCOME screen.


Use the **Cursor** buttons (↑, ↓, <, >) to highlight an option, then press ↵ to make and/or save settings.

Use the **Number** buttons to make numeric entries.




### 2. Enter Admin Code

The first screen displayed will be blank. Use the number buttons to type the provided four digit Admin Code: "1-2-3-4".



Entries will be represented by asterisks. Press ↵ to enter the code.



**Note:** If an error is made entering the code, you will be prompted. Follow on-screen instructions, then try again.



### 3. Create a New Admin Code

All panels require a new password upon start up.


Enter the initial four digit entry code, you'll be prompted to enter and verify a new Admin Code.




**Note:** If an error is made entering the code, you will be prompted. Follow on-screen instructions, then try again.

### 4. Panel Settings

After successfully entering a new Admin Code, the Panel Settings screen is displayed.



**IMPORTANT:** If the Panel Settings screen times out or you leave the screen voluntarily, refer to the process described in **Step 5** to return to the Panel Settings screen. Otherwise, proceed to step 6.






### 5. Returning to Panel Settings Screen

1. Press the HOME button until you arrive at the Building Name/Address screen.

2. Highlight the Gear icon (⚙️), then press ↵.


3. At the Settings screen, enter 99, press the HOME button and then enter the Admin passcode.

The Panel Setting screen should be displayed. If not, repeat the three steps listed above.




## 6. Access Attempts Settings

Select **Access Settings** from the Panel Settings screen to view the following options:




**Access Attempts:** Sets the maximum number of attempts before access lockout. **Default** = 3.

**Lockout Time:** Sets the lockout time for maximum Access Attempts reached. **Default** = 30 Sec.




## 7. Audio Settings

Select **Audio Settings** from the Panel Settings screen.



**Speaker and Keypad Volume:** Both of these volume options are adjusted in the same manner.

Set the volume option to *Loud*, *Normal* or *Soft*. **Default** = Normal.






## 8. Call Settings

Select **Call Settings** from the Panel Settings screen.

**Visitor Talk Time:** Sets a time limit for visitor communication at the console. Set from 30 seconds to 5 minutes. **Default** is 60 Sec.


**Visitor Talk Extension Time:** Extends the Visitor Talk Time setting. Set from 10 seconds to 60 seconds. **Default** = 30 Sec.

**Maximum Call Extensions:** Select from 1 to 3 Extensions, or set to **Disable**. **Default** = 1 Extension.




## 9. Device Settings


Select **Device Settings** from the Panel Settings screen.



**Proximity Sensor:** Enables or disables the Proximity Sensor. **Default** = Enabled.




**Panel Lighting:** Sets panel light duration with options ranging from 15 seconds to 5 minutes. **Default** = 30 Sec.




## 10. Display Settings


Select **Display Settings** from the Panel Settings screen.



**Backlight Setting and Keypad Setting:** Both settings offer the same options. Select *Auto*, *Bright*, *Normal* or *Dim*. **Default** = Auto.




**Screen Timeout:** Sets screen panel light timeout duration with options ranging from 10 seconds to 60 minutes. **Default** = 10 Sec.



## 11. Microphone Settings

Select **Microphone Settings** from the Panel Settings screen.


Set the microphone sensitivity option to *High*, *Medium* or *Low*. **Default** = Medium.





## 12. System Settings

Select **System Settings** from the Panel Settings screen.



**Time and Date:** Both settings are set in the same manner. Set to the current Time and Date.

**Time Zone:** Scroll to find the correct time zone, then press .






## 13. Settings


Press the HOME button until you arrive at the Building Name/Address screen.

Select the Gear icon , then press  to access the Settings screen.


**Volume:** Set the console speaker Volume option to *Loud*, *Normal* or *Soft*. **Default = Normal.**



**Text Size:** Set the console text size option to *Small*, *Medium* or *Large*. **Default = Medium.**



**Display:** Set the LCD display brightness to *Bright*, *Normal* or *Dim*. **Default = Normal.**




Press the HOME button twice to return to the Building Name/Address screen.



Test the system.

**Note:** Any Settings changes made will reset to defaults once the Welcome screen times out.


## 14. Using the Directory


Press the HOME button until you arrive at the Building Name/Address screen.

**Directory:** To call a resident, use the **Cursor** buttons (< >) to select the first letter of the resident's last name. Use the **Cursor** buttons (^ v) to select a name, then press  to make the call.



## 15. Entering a Code

**Enter Code:** If you already know the number of a resident to call, enter the code and press .



Please consult the EN Series Programming Guide for additional programming information.

### NORTEK SECURITY & CONTROL LIMITED WARRANTY

This Nortek Security & Control product is warranted against defects in material and workmanship for twelve (12) months. This warranty extends only to wholesale customers who buy direct from Nortek Security & Control or through Nortek Security & Control's normal distribution channels. Nortek Security & Control does not warrant this product to consumers. Consumers should inquire from their selling dealer as to the nature of the dealer's warranty, if any. There are no obligations or liabilities on the part of Nortek Security & Control LLC for consequential damages arising out of or in connection with use or performance of this product or other indirect damages with respect to loss of property, revenue, or profit, or cost of removal, installation, or reinstallation. All implied warranties, including implied warranties for merchantability and implied warranties for fitness, are valid only until the warranty expires. This Nortek Security & Control LLC Warranty is in lieu of all other warranties express or implied.

All products returned for warranty service require a Return Product Authorization Number (RPA#). Contact Nortek Security & Control Returns at 1-855-546-3351 for an RPA# and other important details.

**NORTEK™**  
SECURITY & CONTROL