



## GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST


### OPERATOR HEAD PARTS



### LSO & LCO



### LDO




### LSO, LDO, & LCO


ITEM #	REPLACEMENT PART	PART #
1	REAR LSO & LCO END COVER (WITH LABELS)	HAE00041
2	MAIN LSO COVER (WITH LABELS)	HAE00026
3	MAIN LCO COVER (WITH LABELS)	HAE00042
4	FRONT LSO COVER (WITH LABELS)	HAE00028
5	FRONT LCO COVER (WITH LABELS)	HAE00043
6	LSO & LCO LENS COVER (FITS BOTH ENDS)	220918
7	LSO MOTOR	220919
8	LCO MOTOR	220919
9	1/3 HP LDO COVER (WITH LABELS)	HAE00011
10	1/2 HP LDO COVER (WITH LABELS)	HAE00012
11	LDO LENS COVER	217645
12	LDO MOTOR	217881
13	CONTROL BOARD (LOGIC/RECEIVER/TORQUE)	HAE00040
14	LAMP SOCKET ASSEMBLY	218014-02
15	1/3 HP CAPACITOR (43-53 MFD) <i>FOR LDO33 ONLY</i>	219109
16	1/2 HP CAPACITOR (53-64 MFD) <i>FOR LDO50 ONLY</i>	219110
17	3/4 HP CAPACITOR (65 MFD) <i>FOR LCO75 ONLY</i>	232168
18	HELICAL AND WORM GEARS (WITH GREASE)	HAE00047
19	HELICAL GEAR (WITH GREASE)	HAE00048
20	LIMIT SWITCH ASSEMBLY	HAE00004

## GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST

### DC OPERATOR HEAD PARTS




LDCO 800



LDCO 850, 852, 841, 863B

ITEM #	REPLACEMENT PART	PART #
1	LDCO CONTROL BOARD, BBU COMPATIBLE (800/801)	HAE00077
2	LDCO FRONT COVER (WITH LABEL) (800/801)	HAE00051
3	BATTERY BACKUP UNIT (800/801)	BBU
4	LDCO ENCODER BOARD (800/801/841/850/852/863B)	HAE00058
5	LDCO MAIN COVER (WITH LABELS) (800/801)	HAE00052
6	LDCO LIGHT LENS (800/801/850)	228152
7	KIT, PCBA, LDCO (841/850/852/863B)	HAE00075
8	TRANSFORMER (841/850/852/863B)	10012046
9	COVER, MAIN (841/863B)	HAE00073
10	BRACKET KIT (852)	10016007
11	REPLACEMENT BATTERY, 12V (841/850/852/863B)	BATT54
12	BATTERY AND HOUSING (841/850)	BATT54BOX
13	BATTERY HOUSING (850/863B)	10015410-004
14	BATTERY HOUSING (852)	10015932-001
15	LED PANEL (841/850)	10014504-01
16	LED PANELS (852)	RP9004
17	LED PANELS (863B)	RP9005

MISCELLANEOUS OPERATOR PARTS




GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST


ITEM #	REPLACEMENT PART	PART #
1	DOOR ARM - STRAIGHT	227966
2	DOOR ARM - BENT	227967
3	SAFETY BEAM SENDER & RECEIVER (WITH WIRE)	HAE00002
4	COMPLETE HARDWARE KIT	220205-02
5	WALL STATION (LDO/LSO/LCO/800)	HAE00001
6	WIFI (SMART) WALL STATION (850/852/841/863B)	HAE00072
7	WIRE KIT (15 SETS OF WIRE AND CLIPS)	HAE00044
8	LDO INSTRUCTIONS AND LABELS	HAE00030
9	LSO INSTRUCTIONS AND LABELS	HAE00031
10	LCO INSTRUCTIONS AND LABELS	HAE00045
11	WIRE CLIP KIT (100 CLIPS)	HAE00019
12	GEL CAP KIT (100 PIECES)	HAE00020

## GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST

### OPERATOR RAIL PARTS



### HBT BELT DRIVE RAILS



### HCT and HCI CHAIN DRIVE RAILS

ITEM #	REPLACEMENT PART	PART #
1	HBT DRIVE SPROCKET	220499
2	HBT PULLEY AND BRACKET	218954-03
3	HBT INNER SLIDE ASSEMBLY	HAE00022
4	TROLLEY ASSEMBLY	218189-01
5	7 FOOT BELT ASSEMBLY	HAE00023
6	8 FOOT BELT ASSEMBLY	HAE00033
7	DRIVE SPROCKET HOLDER AND BELT CLAMP <i>BELT CLAMP FOR USE ON HBT BELT RAILS ONLY</i>	HAE00049
8	HCT DRIVE SPROCKET	217436
9	HCI DRIVE SPROCKET	227653
10	HCT PULLEY AND BRACKET	HAE00014
11	HCT TURNBUCKLE ASSEMBLY	HAE00013
12	HCT INNER SLIDE ASSEMBLY	HAE00018
13	CENTER SUPPORT BRACKET	CSB
14	7 FOOT CHAIN ASSEMBLY	HAE00015
15	8 FOOT CHAIN ASSEMBLY	HAE00032
16	10 FOOT CHAIN ASSEMBLY	HAE00017
17	12 FOOT CHAIN ASSEMBLY	HAE00046